


## **CABINET PARTS**

For Models: KBCS24RSBS00, KBCS24RSSS00 (Black Cabinet) (SS Cabinet)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	13	4344771	Bracket, Grille	26	4344827	Screw
	2300276	Use & Care Guide	14	4344841	Evaporator Fan	27	4344792	Thermal Fuse
	4344901	Wiring Diagram			Assembly	28	4344793	Screw
2		Cabinet (Not A	15	4344860	Thermostat	29	4344791	Screw
		Service Part)	16	4344768	Knob, Thermostat	30	4344783	Fan Blade
3	4344739	Lens, Light (	17	4344767	Switch, Plunger	31	4344878	
4		Bulb, Light	18	4344826		32	4344865	Evaporator Fan
5	4344746	Heater, Defrost	19	4344797	Screw			Motor
6	4344747	Heat Shield	20	4344819	Clip, Grille	33	4344877	Harness, Wire
7	4344761	Grille	21	4344825	Screw	34	4344832	Screw, Ground
8	4344762	Plate, Bottom	22	4344823	Seal	35	4344778	Grommet, Fan Motor
9	4344763	Foot, Leveling	23		Frame, Support	36	4344899	Bracket, Motor
10		Brace, Support		4344821	Right	37		Evaporator
11	4344898	Control Box		4344820	Left			(Not Serviced)
12		Frame, Side	24	4344824	Clip, Harness	38	4344858	Switch, Light
	4344769	Left Side	25	4344857	Harness, Wire	39	4344917	Transformer Cable
	4344770	Right Side				40	4344918	Temperature Sensor

## **SHELF PARTS**

For Models: KBCS24RSBS00, KBCS24RSSS00 (Black Cabinet) (SS Cabinet)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4344892	Temperature	10	4344882	Trim, Top And	17		Shelf, Small
2	1211011	Separator Wine Rack, Top	11		Middle Racks	18 19		Glass, Shelf Trim, Shelf
2 3		Wine Rack, Top Wine Rack, Middle	11	4344866	Support	20		Seal, Rear
3 4		Wine Rack, Islandie Wine Rack, Lower		4344867		20		Seal, Side (2)
5	404040	Ladder, Shelf	12		Trim, Lower Rack	22		Seal, Front
O	4344842	Left Side	13	10 1 1000	Support, Bumper	23		Transformer Cable
		Right Side		4344885		24		PCB Display Board
6	4344794			4344886	Right	25	4344897	
7	4344795	Washer	14		Screw	26	4344905	Support, Shelf
8	4344850	Stop, Lower Rack		4344914	Left			(Large)
9	4344851	Screw		4344915				
			15		Shelf, Large			
			16	4344871	Glass, Shelf			


## **DOOR PARTS**

For Models: KBCS24RSBS00, KBCS24RSSS00 (Black Cabinet) (SS Cabinet) 16 13 11 12 15 21 1 10 19 14 9 - 20

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4344853	Door Assembly	12	4344855	Door Skin, Stainless Steel	20 21	4344801 4344808	
4	4344753	(Includes Gasket) Hinge, Bottom	13	4344760		22		Nameplate
5		Hinge, Top	14	4344788	Spacer, Door			
6	4344755	Spacer, Top Hinge	15	4344904	Plate			
7	4344756		16	4344796	Screw		OPTION	IAL PARTS
		Bottom Hinge	17		Screw, Lower Hinge		NOT II I	USTRATED
8	4344757	Actuator, Switch		4344906	Quantity 1			
9	4344758	Door Stop		4344797	Quantity 3		0474400	Classer Stainless
10	4344852	Door Gasket	18	4344827	Screw		8171420	Cleaner, Stainless
11	4344810	Handle, Door	19	4344799	Screw			Steel (12 oz)

## **UNIT PARTS**

For Models: KBCS24RSBS00, KBCS24RSSS00 (Black Cabinet) (SS Cabinet)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4344772	Drain Pan	13	4344784	Bracket, Motor	28	4344775	Compressor
2	4344773	Bracket,	14	4344785	Bracket, Motor			(Includes Items
		Defrost Timer	15	4344786	Cover, Rear			5, 8, 16, 17 & 21)
3	4344774	Defrost Timer	16	4344837	Capacitor	29	4344834	
4	4344797	Screw	17	4344836	Clip	30	4344833	Screw
5	4344776	Start Device	18	4344839	Tube, Drain	31	4344862	Transformer
6	4344777	Mounting Plate,	19	4344861	Power Cord	32	4344863	Thermostat
		Compressor	20	4344829	Cable Tie	33	4344864	Bracket,
7	4344778	Grommet, Fan Motor	21	4344828	Drier			Thermostat
8	4344779	Grommet,	22	4344838	Bushing	34	4344907	Trim, Edge
		Compressor	23		Clip, Bushing	35	4344908	Support, Drain
9	4344780	Bolt, Compressor	24	4344835	Bushing			
10	4344781	Fan Motor,	25	4344826	Screw	REF	RIGERA	NT CHARGE
		Condenser	26	4344825	Screw			
11	4344782	Baffle, Air	27	4344832	Screw			3.5 Ounces
12	4344783	Fan Blade						(R-134A)